

Tenka Power Guard 2-2 - User Manual

Read carefully before use!

Tenka Power cannot be held responsible for any inaccuracies or inappropriate information in this instruction manual. The information in this document is subject to change without notice, but there is no obligation to update it on an ongoing basis. We reserve the right to make design and equipment changes to improve the production process or the product. Tenka Power accepts no liability for errors in this operating manual and any consequences resulting therefrom.

User Manual:

1. Check the box and verify that it is complete.
2. Determine the installation location and fix the box there.
3. Press all connections into the holes provided to ensure tightness.
4. Please connect all cables now. Please also check the correct cabling.
5. Now insert the enclosed plastic cover and close the box again.

Valid warranty period for general products:

48 months from date of purchase, only for production defects or defective components.

The warranty does not cover the following cases:

- Accident
- Misuse
- Negligence
- Improper installation
- Installation by non-certified personal
- Maintenance by improper installation
- Maintenance by non-certified personal
- Natural factors (e.g. fire, flood)
- Non-compliance with the instructions and specifications described in the operating manual.

No liability for printing errors. Errors and prior sale reserved. Illustrations similar.

Tenka Power GmbH, Bahnhofstrasse 36, 4802 Ebensee, Austria

Tel.: +43 (0)720 531 135, Mail: office@tenkapower.com, Web: www.tenkapower.com

©Tenka Power 2025 | All rights reserved | V2_2025.